



**Comment enregistrer par lot une portier extension à
une station de porte**

Titre:	Comment enregistrer par lot une extension de la station de porte à une station de porte	Version:	v1.0	Date:	2020/11/24
Produit:	Interphone Vidéo			Page:	2 of 4

2. Enregistrement par lot Portier Extension à Station de porte

- 1) Lorsque vous entrez dans la configuration à distance de la station de porte, choisissez **Gestion des appareils**, sélectionnez le **Type d'appareil** comme portier extension, puis exportez les fichiers **Configuration des canaux** pour remplir les

informations de l'appareil.



The screenshot shows the Hikvision web interface. At the top, there's a navigation bar with 'Device Management' selected. Below it, a 'Device List' section has buttons for '+ Add', 'Import', 'Export' (highlighted with a red box), 'Delete', and 'Synchronize'. A dropdown menu for 'Device Type' is set to 'Indoor Station'. Below the buttons is a table header with columns: No., IP Address, Serial No., Model, Current Version, Floor No., Room No., User Name, Network Status, and Operation.

- 2) La page suivante montre les informations que vous devez compléter, toutes les instructions sont données en haut de la liste.

The screenshot shows an Excel spreadsheet with instructions for filling in the 'Door Station List' table. The instructions are:

1. Device Type: Door Station
2. Serial No.: 9-digit serial No. on the tag of the device
3. Sub Door Station Admin Password: Valid password range [8-16]. You can use a combination of numbers, lowercase, uppercase and special character for your password with at least two kinds of them contained.
4. Registration code: For adding the device to the main door station. Valid password range [8-16]. You can use a combination of numbers, lowercase, uppercase and special character for your password with at least two kinds of them contained.
5. Floor No. Range: -10 to 10
6. No. Range: 1 to 16
7. IP Address/IP Mask/Gateway: Supports IPv4



The table below is the 'Door Station List' with the following data:

Device Type	Serial No.	Admin Password	Regist Password	Floor No.	No.	IP Address	IP Mask	Gateway
Door Station	236664759	iqaz2wxs	1234567a	1	1	192.168.1.110	255.255.255.0	192.168.1.254
Door Station	237903914	iqaz2wxs	1234567a	1	2	192.168.1.108	255.255.255.0	192.168.1.254
Door Station	237903927	iqaz2wxs	1234567a	1	3	192.168.1.109	255.255.255.0	192.168.1.254


Red boxes highlight the 'Serial No.', 'Admin Password', and 'Regist Password' columns. A red note says: 'This item must be filled in according to the actual device's serial number.' Another red note says: 'There are configurations we made to the door stations.' A green box highlights the 'IP Address' column.

- 3) Lorsque vous avez terminé les informations sur l'appareil, choisissez **Importer** > **Importer le fichier** > **Parcourir**, téléchargez le fichier.

Titre:	Comment enregistrer par lot une extension de la station de porte à une station de porte	Version:	v1.0	Date:	2020/11/24
Produit:	Interphone Vidéo			Page:	3 of 4




4) Lorsque vous aurez terminé d'importer les informations sur l'appareil, vous constaterez la situation suivante.



Titre:	Comment enregistrer par lot une extension de la station de porte à une station de porte	Version:	v1.0	Date:	2020/11/24
Produit:	Interphone Vidéo			Page:	4 of 4

- 5) Assurez-vous que les numéros de chambre que vous avez définis auparavant **ne sont pas en conflit les uns avec les autres**, puis attendez 2 à 8 minutes, les appareils seront en ligne.



The screenshot shows the Hikvision Device Management interface. At the top, there is a navigation bar with the Hikvision logo and menu items: Live View, User, Number Settings, Device Management (highlighted), and Configuration. Below the navigation bar, there is a 'Device List' section. It includes a toolbar with icons for Add, Import, Export, Delete, and Synchronize, along with a Status dropdown menu set to 'All' and a Device Type dropdown menu set to 'Sub Door Station'. The main part of the screenshot is a table with the following columns: No., IP Address, Serial No., Model, Current Version, Floor No., No., User Name, Network Status, and Operation. Three rows of data are visible, each with a 'Network Status' of 'Online' and a green checkmark icon. The 'Network Status' column for these three rows is highlighted with a red box.

No.	IP Address	Serial No.	Model	Current Version	Floor No.	No.	User Name	Network Status	Operation
1	192.168.1.110	236664759	DS-KV8413-...	V2.2.3 build 20	1	1	admin	Online	[Edit] [Delete]
2	192.168.1.108	237903914	DS-KV8113-...	V2.2.3 build 20	1	2	admin	Online	[Edit] [Delete]
3	192.168.1.109	237903927	DS-KV8113-...	V2.2.3 build 20	1	3	admin	Online	[Edit] [Delete]

Remarque : Le mot de passe d'enregistrement est le mot de passe qui doit être configuré pour l'appareil activé. Lorsque la station de porte ajoute une station intérieure activée, le mot de passe d'enregistrement de la station intérieure doit être connu. La station intérieure inactive peut être attribuée directement par la station de porte.



See Far, Go Further